



Outside Conn. Outlets over doors to be in center of wide trim board above transoms

12 Show window lights each side
 Note: TIME SWITCHES FOR CONTROL OF SHOW WINDOW LIGHTS TO BE UNDER PANEL AT 'X'. ALL CIRCUITS FOR SHOW WINDOWS & SIGN TO COME THRU LARGE JUNCTION BOX NEAR 'X' SO THEY CAN BE TRANSFERRED TO TIME SWITCH CONTROL.

ELECTRIC WIRING DIAGRAM
FIRST FLOOR.

SCALE 1/4" = 1'-0"

NOTE - See Bsmt. Plan for Key to symbols - Genl. Notes etc.

REVISED 10/14/41
 FILE NO. 27-G

9986 Wheelwright Collection
 Blueprints: 54, Inland, Seal