



NOTES

1. ALL PIPE UNDER SLAB BE COPPER
2. NO SOLDER JOINTS UNDER SLAB
3. STOPS REQUIRED ON ALL RUNS
4. ALL RUNS TO HAVE AIR CHAMBERS OR SHOCK ABSORTERS

8816 Wheelwright Collection  
 Blueprints: 174, Mantain Investment

PLUMBING PLAN		
ECONOMY 1200		
DATE SEPT 76	SCALE NONE	PAGE 11
DESIGNED BY - CR LEADINGHAM		
CONSTRUCTION SERVICES		